

OID set by PJP/Print job

How can I set OID's without tools

OID's can be set without SNMPSET or other SNMP tools. It works also by sending a print job.

PJP Sample

To set an OID, for example to set the SYSNAME of the device, following print job can be sent to the device (by PORT 9100, or FTP):

```
?<esc>%-12345X@PJP  
@PJP COMMENT "SYSNAME"  
@PJP KSETOBJ OBJ = ".1.3.6.1.2.1.1.5.0" VALUE = ""  
?<esc>%-12345X
```